

1. Preparation & Acclimatisation

Proper preparation is critical to the performance and longevity of the Superstrata system. The subfloor must be structurally sound, clean, dry, and flat to SR2 tolerance (maximum 3mm deviation under a 2m straight edge).

- Remove all dust, debris, paint, oil or existing floor coverings.
- Ensure concrete subfloors are fully cured (typically 28 days) and moisture levels are within acceptable limits.
- Lay the turf out flat at least 24 hours prior to installation to allow it to acclimatise to the ambient temperature and humidity.

2. Required Tools

- Reinforced double-sided tape

3. Installation Method

1. Lay the turf down where it is to be finally positioned and roll up half of the turf.
2. Apply reinforced double-sided tape to the subfloor area where the turf is to be placed, in parallel lines in a vertical direction. Wait the recommended time as per adhesive label instructions. Gently place the turf into position and press lightly around edges.
3. Roll up the other half of the turf and repeat the same process. Roll back into position.

4. Maintenance & Cleaning

- Daily: Use a wide, soft brush or rake with rubber teeth to remove any surface debris.
- Weekly: Gently vacuum for any embedded dirt or debris.
- Monthly: Deep clean the turf with a suitable mild detergent to keep sanitised. Do not use excess water or harsh chemicals.